
# **Power Electronics**


# **MINISTOP Motor Brake Relav** BN 9034, GB 9034



#### **Function Diagram**



**Circuit Diagrams** 



#### Translation of the original instructions

- DC brake with one way rectifier up to 600 A •
- Can be used on all asynchronous motors
- Easy to fit also into existing control circuits
- Wear and maintenance free
- Integrated braking contactor for devices up to 60 A
- Mounting on 35 mm DIN-rail for 25 A units
- Adjustable braking current
- With automatic standstill monitoring
- As option with start-delta start function
- As option with thermistor motor protection
- As option with wide voltage input
- BN 9034: 200 ... 575 V
- GB 9034: 200 ... 690 V Width max. 310 mm

# **Approvals and Markings**




#### Application

- Saws
- Centrifuges
- Woodworking machines
- Textile machines
- Transportation conveyors •

# Function

The supply voltage is connected to terminals L1-L2. The interlock contact for the motor contactor closes. The LED "ready" indicates that the supply voltage is connected. The motor can be started with the start button. The DC voltage for the motor windings UV is supplied from T1-T2. The external braking contactor (Devices for > 60 A) is controlled by contact 1-2. This contact is timed in a way, that a safety time is provided between reset of the motor contactor and start of the brake contactor. This is necessary to avoid damage of the semiconductors by induced back EMF voltage. The timing of the different functions during braking is as follows: The motor contactor is switched off and disconnects the motor. After elapse of the safety time, the brake contactor is energized and shortly after that the brake current is switched on for the adjusted braking time.



All technical data in this list relate to the state at the moment of edition. We reserve the right for technical improvements and changes at any time.

# Indicators BN 9034

LED "ready":	On, when supply voltage connected
	flashing, when braking current is adjusted too high.
LED "I":	On, when braking current is flowing.

Notes

For optimum braking effect, the braking current should be 1,8 ... 2 times the nominal motor current. This current corresponds to the necessary saturation current of the magnetic field needed for braking. Higher currents show not much more effect, but will heat up the motor. A better braking effect is achieved by using more then one motor winding for braking. The permitted braking ration relates to the braking current, the ambient temperature and the brake model.

#### ATTENTION



The terminal W or T3 serves as measuring input for the standstill monitoring, with 2.5 mm<sup>2</sup> max. cross section. With devices for > 40 A a fuse must be used to protect this connection wire at the point where the wire with smaller cross section is connected to the motor line. The choice of the fuse is suited to the used crossed section and serves the short circuit protection of the line.

#### **Technical Data**

Nominal voltage $[U_N]$ :		others		00 V ± V / 690		equest	
Nom. frequency [Hz]:	50/60						
	BN 9034			G 90	B 34		
Motor power [kW] at 400 V:	5.5	7.5	15	22	55	110	160
Max. adjustable bra- king current [A]:	25	40	60	100	200	400	600
ED at max. braking current [%]:	8	20	20	20	20	20	20
Fuse, superfast [A]:	25	40	60	100	200	400	630
Braking voltage:			DC	0 23	0 V 0		
Max. braking time [s]:	15			32	20		
Back-EMF braking time delay:	selfoptimizing (100 2500 ms)						
Connection diameter (max.)							
Box terminal [mm <sup>2</sup> ]:	1.5	16	16	16	35		
Screw terminal:						M12	M12
Power consumption for electronic [VA]:				6			
Contacts:				O conta / AC 25			
Temperature range [°C]:	0 + 45						
Storage temperature [°C]:	- 25 + 75						
Degree of protection:	IP 20 (25 A)			IP (40	20 600 A)		
Mounting:	to 25 A mounting on DIN-rail to 40 A screw fixing M5						
Weight [kg]:	0.8	2.1	2.1	2.1	3.1		


# Technical Data

#### **Dimensions:**

# Width x height x depth

BN 9034:





	Α	в	С	D	Е	F
40 A	110	242	140	86	226	-
60 A	110	242	140	86	226	-
100 A	110	242	140	86	226	-
200 A	110	255	155	80	226	-
400 A	210	275	165	180	226	340
600 A	310	280	165	280	226	355
Dimens	ions in	mm				

40-100 A	PE	L1	U	L2	V	PE
200 A	PE	L1	U	L2	V	
400 A	PE	L1/U	L2	V		
600 A	L1/U	PE	V	L2		
Wire connection configuration						

### **Standard Type**

#### BN 9034 25 A AC 400 V 50/60 Hz 15 s Article number: 0057148 Integrated braking contactor

- Mounting on 35 mm DIN-rail

- Width:


# Variant

variant	
BN 9034 / _	1: Thermistor-motor protection input 1: Star-delta control 1: Output relay for standstill indication 1: Wide voltage input (U <sub>N</sub> = 200575 V)

100 mm

The 4 options can be ordered single or in combinations.

The variant with wide voltage input needs an auxiliary supply of AC 230 V or Ac 24 V.



# Inputs BN 9034

Opening the contact on terminal X3 and X4 makes the device ready for braking. When the contact is closed the braking current starts to flow. X14-X15 monitors the motor temperatur (option)


Outputs BN 9034	
X5, X6:	Interlock for monitor contactor
X16, X17:	Standstill indication (option)
X7, X8:	Fault indicating output
X11, X12:	Control of Y-contactor (option)
X12, X13:	Control of $\Delta$ -contactor (option)

Setting facilities BN 9034				
Potentiometer	function	initial setting		
I t <sub>1</sub> n <sub>0</sub> t <sub>2</sub>	braking current braking time standstill level 2. braking time	left end of scale middle of scale middle of scale left end of scale		

# **Standard Type**


GB 9034	100 A	AC 400 V	50/60 Hz	
		710 400 V		
Article number: 0056975				
<ul> <li>Screw f</li> </ul>	ixing MS	5		
• Width:			110 mm	

# Variant



The 4 options can be ordered single or in combinations.

The variant with wide voltage input needs an auxiliary supply of AC 230 V.



# Inputs GB 9034

Z3, Z4:	Motor PTC
Z1, Z2:	Braking interrupt
Z1, X3:	2. braking time
6,7:	Start of braking


#### Outputs GB 9034

1,2:	External braking contactor
8,9:	Interlock for motor contactor
33,34:	Fault indication output
43,44:	Control of Y-contactor (option)
43,45:	Control of $\Delta$ -contactor (option)
13,14	Standstill indication (option)
13,24	Braking current too low (option)
-	<b>o (() )</b>


### Set-up Procedure

The braking time cannot be set on the unit BN 9034. It is limited by the standstill detection. If the feedback input T3 is not connected to terminal W of the motor the standstill detection is disabled and the internal max. braking time of 15 is valid. The GB 9034 allows to set different braking times and can be used for standstill depending as well as time depending braking function. More details are available in the operating manual.


With potentiometer I the braking current can be adjusted. With a current meter (true RMS) the current should be measured so that 2 times the braking current is not exceeded in order not to overheat the motor. The braking device cannot be overloaded, as it limits the current even on full potentiometer setting to the nominal current of the unit. This status is indicated by the flashing "ready" LED.



for BN 9034 25 A



for GB 9034 40 A, 60 A



for GB 9034 from 100 A

E. Dold & Söhne GmbH & Co. KG • D-78120 Furtwangen • Bregstraße 18 • Phone +49 7723 654-0 • Fax +49 7723 654356